




Configuraciones ver
Configuration see
Configurations voyez
Komponenten siehe

DS.0822.02
DS.0822.01




n°	Ref.	Ø	h	n°	Ref.	Ø	h	n°	Ref.	Ø	h
1	MT123	1,2	10,1	5	MH121	1,2	3,0	9	TS14	1,6	5,5
2	MT123A	1,2	10,1	6	S15	1,6	5,5	10	S13	1,6	5,5
3	MH124A	1,2	11,8	7	TS15	1,6	5,5	11	S12	1,6	5,5
4	MH124-1	1,2	11,8	8	S14	1,6	5,5	12	TMS13	1,6	1,0





Configuraciones ver
Configuration see
Configurations voyez
Komponenten siehe

DS.0822.02
DS.0822.01



n°	Ref.	Ø	h	n°	Ref.	Ø	h	n°	Ref.	Ø	h
1	MT123	1,2	10,1	5	MH121	1,2	3,0	9	TS24	2,0	5,5
2	MT123A	1,2	10,1	6	S25	2,0	5,5	10	S23	2,0	5,5
3	MH124A	1,2	11,8	7	TS25	2,0	5,5	11	TMS23	2,0	1,0
4	MH124-1	1,2	11,8	8	S24	2,0	5,5				

